

Sole-Mate™

Static Dissipative Footwear Test Station

The **Sole-Mate™** is a user friendly device that is designed to test the condition of static dissipative footwear prior to entering safety critical hazardous areas exposed to potentially ignitable atmospheres.

Enquiry > Click here to submit a product related query or a request for quotation.

International Standards (detailed on the next page) recommend regular testing of static dissipative footwear. The **Sole-Mate** provides a time efficient and cost effective method of ensuring personnel operating in hazardous areas are wearing static dissipative shoes that are capable of preventing electrostatic charge accumulation on their bodies.

The **Sole-Mate** tests the condition of the shoes by measuring the resistance of the electrical loop through the operator and their footwear. If the resistance of the shoes is too high, the **Sole-Mate** will indicate that the shoes have failed the test via a red lamp and buzzer alarm. If the shoes pass the test a green lamp will indicate to the operator that the shoes are fit for purpose.

Additionally, users can interlock the tester with audible alarms or entry doors into hazardous areas so that personnel not wearing suitable footwear cannot enter the hazardous area.

All **Sole-Mate** units are supplied with 3 m cable to wire into a mains supply. The U.S. unit is supplied with 6 ft. cord and U.S. 3 prong plug.

- > Upper level resistance options available
- > Sole-Mate resistance level tester
- > IP65 industrial standard enclosure



Sole-Mate Static Dissipative Footwear Test Station



Sole-Mate™ Static Dissipative Footwear Test Station

Relevant International Standards

Based on user preference, the Sole-Mate can be ordered to measure upper level resistance as defined by the following standards:

- > EN ISO 20345 — 1x10⁹ ohm
- > IEC 60079-32 — 1x10⁸ ohm
- > ASTM F2413-05 — 1x10⁸ ohm

PLEASE NOTE: Equipment specifiers must ensure that the Sole-Mate Tester resistance level selected is compatible with the static dissipative shoes in use within the hazardous area. E.g.: a 1x10⁸ resistance level should not be selected for EN ISO 20345 compatible shoes.

Sole-Mate Resistance Tester VESF59 & VESF59/A

The resistance test unit can be used at regular intervals (every 6 or 12 months) to ensure the upper resistance threshold of the footwear tester is operating at the correct level.

Contact Us > Your enquiry will be processed rapidly via our webform enquiry service. If you would prefer to call us, or e-mail us, please use the contact details provided below.

Product Ordering Codes

Ordering Code	Product Description
SM2/108E	1 X 10 ⁸ 115 - 230 Vac (Euro cable)
SM2/108U	1 x 10 ⁸ 115 - 230 Vac (US cable and plug)
SM2/109E	1 x 10 ⁹ 115 - 230 Vac (Euro cable)
SM2/109U	1 x 10 ⁹ 115 - 230 Vac (US cable and plug)
VESF59	1 x 10 ⁹ Sole-Mate Resistance Level Tester
VESF59/A	1 x 10 ⁸ Sole-Mate Resistance Level Tester

The Sole-Mate™ forms part of the Static Grounding and Bonding Equipment available from Newson Gale.

United Kingdom
 Newson Gale Ltd
 Omega House
 Private Road 8
 Colwick, Nottingham
 NG4 2JX, UK
 +44 (0)115 940 7500
 groundit@newson-gale.co.uk

Deutschland
 IEP Technologies GmbH
 Kaiserswerther Str. 85C
 40878 Ratingen
 Germany
 +49 (0)2102 5889 0
 erdung@newson-gale.de

United States
 IEP Technologies LLC
 417-1 South Street
 Marlborough, MA 01752
 USA
 +1 732 961 7610
 groundit@newson-gale.com

South East Asia
 Newson Gale S.E.A. Pte Ltd
 136 Joo Seng Road, #03-01
 Singapore
 368360
 +65 6704 9461
 ngsea@newson-gale.com